

## Technical Specifications

Materials	Steel
Connections	½" flow and return.
Test pressure	12 Bar
Testing authority	EN442
Maximum operating pressure	8 Bar
Maximum working temperature	95°C
Packaging	Encased in polystyrene, seated within a cardboard box

PLEASE NOTE: Systems using micro bore pipework must have adequate pressure and flow rates for the number and style of radiators on the system.

## Terms & Conditions

All products must be inspected once removed from the packaging and The Radiator Company notified within 28 days of delivery of any scratches, blemishes or other damage. The Radiator Company will then replace the radiator.

Imperfect radiators should therefore not be fitted and The Radiator Company will not accept responsibility for replacement of scratched or damaged radiators once they have been fitted. This includes any consequential loss or cost of fitting.

If The Radiator Company are not notified within 28 days of the date on the signed delivery note then it will be deemed that The Radiator Company have fully complied with its obligations and claims will not be considered.

Failure to comply with any of the above may invalidate any claims.

We recommend that after you check the product on delivery that it is stored in its packaging to prevent damage prior to installation. The Radiator Company cannot accept responsibility for items damaged after delivery.

## Guarantees & Liabilities

As we are not the manufacturers of this product we will take all reasonable endeavours to make over to you the benefit of any warranty or guarantee given by the manufacturer, which is usually five years on most of our range. (Copies of specific guarantees for any of our products are available on request).

The guarantees in all cases are subject to the products being installed in accordance with British and or European standards as well as these fitting instructions. The guarantees in all cases are restricted to the free of charge replacement or repair of the failed product only. Our liability will under no circumstances extend beyond the repair or replacement of the product supplied by us. Claims for either labour in replacement or damage to property are not admissible. Any goods that are returned, in the event of a problem, will belong to The Radiator Company.

## Fittings Instructions



The Halo is a classic contemporary design. Industrial and low level in style, the design works well in open plan areas with large expanses of glass.

Please read these instructions and terms and conditions carefully prior to installation. Failure to do so may invalidate the warranty

The Radiator Company  
Units 13 - 14 Charwoods Road  
East Grinstead  
West Sussex  
RH19 2HU



HALOH1.2


## Technical Data

### Fixing Centres


130mm Height = Length (mm) - 90mm

190mm Height = Length (mm) - 96mm


250mm Height = Length (mm) - 96mm




### 130mm Height



### 190mm Height



### 250mm Height



## Pipe Centres

Pipe centres left to right = width plus valves

Pipe centres from wall

130mm Height = minimum of 65mm

190mm Height = minimum of 90mm

250mm Height = minimum of 120mm

## 1 Unpack & Inspect

The Radiator Company prides itself on selecting products from manufacturers who exercise tight quality control measures. We only select models with excellent standards of welding and brazing, as well as high quality finishes. All of our products are well packaged and should reach you in perfect condition. Just in case however, we offer a minimum 5-year no quibble guarantee for all radiators and towel rails.

The Radiator Company must be notified of any shortages or damage within 28 days of delivery. For further information please see terms and conditions on back page.



**Please Note:** This radiator may only be installed horizontally on floor

## 2 Contents

You should have:

- 1 Radiator
- 1 Air Vent
- 1 Air Vent Key

You will need:

- 6 Screws; 4mm dia x 60mm
- Suitable Valves
- PTFE tape
- Silicone thread sealant
- Tape measure
- Spanner; 17mm
- Screwdriver
- Electric drill
- Suitable drill bit


## 3 Fit Radiator

**Please Note:**

Sufficient PTFE tape must be applied to valve threads prior to their installation. Silicone thread sealant should be applied to all threaded components manufactured with 'O-Rings'.

**Assembly Instructions:**

- 1) Fit valves (not supplied).
- 2) Fit supplied air vent (A)
- 3) Accurately mark out holes for mounting feet on floor to dimensions shown within the Technical Data section (see left).
- 4) Once marked out, drill four holes to suit screws (B)
- 5) Fix radiator to floor with screws (B)



## 4 Commission Radiator

**Please Note:** In accordance with Part L1 2006 of the Building Regulations and BS7593:1992 code of practice for the treatment of hot water and central heating systems, we strongly recommend flushing the heating system post installation of new radiators and then adding the correct quantity and type of inhibitor for use with your radiator and system to prevent corrosion. Damage caused to systems not protected by a suitable inhibitor will not be covered by manufacturer's guarantee.

## Technical Specifications

Materials	Steel
Connections	½" flow and return.
Test pressure	12 Bar
Testing authority	EN442
Maximum operating pressure	8 Bar
Maximum working temperature	95 °C
Packaging	Encased in polystyrene, seated within a cardboard box

**PLEASE NOTE:** Systems using micro bore pipework must have adequate pressure and flow rates for the number and style of radiators on the system.

## Terms & Conditions

All products must be inspected once removed from the packaging and The Radiator Company notified within 28 days of delivery of any scratches, blemishes or other damage. The Radiator Company will then replace the radiator.

Imperfect radiators should therefore not be fitted and The Radiator Company will not accept responsibility for replacement of scratched or damaged radiators once they have been fitted. This includes any consequential loss or cost of fitting.

If The Radiator Company are not notified within 28 days of the date on the signed delivery note then it will be deemed that The Radiator Company have fully complied with its obligations and claims will not be considered.

Failure to comply with any of the above may invalidate any claims.

We recommend that after you check the product on delivery that it is stored in its packaging to prevent damage prior to installation. The Radiator Company cannot accept responsibility for items damaged after delivery.

## Guarantees & Liabilities

As we are not the manufacturers of this product we will take all reasonable endeavours to make over to you the benefit of any warranty or guarantee given by the manufacturer, which is usually five years on most of our range. (Copies of specific guarantees for any of our products are available on request).

The guarantees in all cases are subject to the products being installed in accordance with British and or European standards as well as these fitting instructions. The guarantees in all cases are restricted to the free of charge replacement or repair of the failed product only. Our liability will under no circumstances extend beyond the repair or replacement of the product supplied by us. Claims for either labour in replacement or damage to property are not admissible. Any goods that are returned, in the event of a problem, will belong to The Radiator Company.

## Fittings Instructions



The Halo is a classic contemporary design. Industrial and eye catching making use of tall spaces.


Please read these instructions and terms and conditions carefully prior to installation. Failure to do so may invalidate the warranty

The Radiator Company  
Units 13 - 14 Charlwoods Road  
East Grinstead  
West Sussex  
RH19 2HU



HALOV1.2

## Diagrams of Halo




## Pipe Centres

Pipe centres left to right	60mm
Pipe centres from wall	148mm
Depth from wall	225mm

### 1 Unpack & Inspect

The Radiator Company prides itself on selecting products from manufacturers who exercise tight quality control measures. We only select models with excellent standards of welding and brazing, as well as high quality finishes. All of our products are well packaged and should reach you in perfect condition. Just in case however, we offer a minimum 5-year no quibble guarantee for all radiators and towel rails.



The Radiator Company must be notified of any shortages or damage within 28 days of delivery. For further information please see terms and conditions on back page.

### 2 Contents

You should have:

- 1 Radiator
- 1 Airvent
- 1 Fixing Kits including: 4 screws and 4 wall plugs

You will need:

- Tape measure
- Electric drill and bits
- Spirit level



**Please Note:** The supplied fixings are not suitable for all wall types. Please ensure the correct fixings are used for your wall type.

### 3 Hang Radiator

1. Hold up the radiator to the wall and mark through the drill holes of the brackets.

2. Take down the radiator and using a spirit level, ensure the brackets are vertically aligned.

3. With the bracket markings level, fix the bracket to the wall using suitable drill bits and plugs.



#### PLEASE NOTE :

It is essential that all brackets are level to ensure a vertical alignment for connecting the pipework.

### 4 Commission

**Please Note:**

In accordance with Part L1 2006 of the Building Regulations and BS7593:1992 code of practice for the treatment of hot water and central heating systems, we strongly recommend flushing the heating system post installation of new radiators and then adding the correct quantity and type of inhibitor for use with your radiator and system to prevent corrosion. Damage caused to systems not protected by a suitable inhibitor will not be covered by manufacturer's guarantee.